



PO Box 105262
Jefferson City, MO 65110-5262
(573) 635-6477
E-Mail:

Panasonic DBS 576 Setting System Time & Date

- 1) If not already in User Maintenance Mode, enter User Maintenance Mode.
To enter User Maintenance Mode:
 - a. At a telephone with a COS that allows user login, press the **ON/OFF** key.
 - b. Press the **PROG** key.
 - c. Press the * key twice (**).
 - d. Press the **CONF** key.
- 2) At the 81 level (User Maintenance), enter 000.
- 3) Press the **HOLD** key.
- 4) Enter the year (2 characters), month (two characters), and day (2 characters).
 - a. NOTE: To clear an entry or existing data, press the **FLASH** key.
- 5) Press the **HOLD** key.
- 6) Enter the hour (2 characters) and minute (2 characters).
- 7) Press the **HOLD** key.
- 8) Enter the day of week where: 1 = Monday, 2 = Tuesday, 3 = Wednesday, 4 = Thursday, 5 = Friday, 6 = Saturday, and 0 = Sunday.
- 9) Press the **HOLD** key to store the entry.
- 10) To return to the top menu level (81), press the **PROG** key. OR... to exit the User Maintenance mode, press the **ON/OFF** key.